# 1. Introduction

This product is designed to hang motorcycle cases on a wall. It consists of base plates and model-specific holders and spacers. The motorcycle cases are securely held by the integrated mounting hooks. The spacers align the cases in a vertical position.

Contents:

- Base plate   2 pieces
- Upper holder   4 pieces
- Lower holder   4 pieces
- Tube   2 pieces
- Countersunk screw M5x10   4 pieces
- Hexagon screw M5x25   4 pieces
- Wood screw 3.5x25 PZ2   8 pieces

upper holders

Lower holders

tube

Base plate

Safety instruction

General Safety Instructions

Read this manual carefully before starting the assembly.
Keep this manual for future reference.
Keep children and pets away during assembly and use.

Warnings

Ensure that the wall where the bracket is mounted is stable and load-bearing.
Only use the supplied mounting screws and dowels.
Regularly check the fastenings to ensure they are secure. Do not expose the product to the elements, as the plastic can quickly degrade with exposure to UV radiation, wind, and rain.

2. Preparation

Tools and Materials

For the assembly of the wall bracket, you will need the following tools and materials:

- Drill and drill bits
- Screwdriver or cordless screwdriver
- Spirit level
- Tape measure or ruler
- Pencil for marking

Preparing the Installation Site

1. **Select a wall**: Choose a stable and load-bearing wall that can safely support the weight of the motorcycle cases.
2. **Clear the area**: Clear the area around the installation site to have enough space to work.
3. **Set markings**: Use the spirit level and pencil to mark the position of the base plates on the wall. Ensure the markings are straight and at the desired height.

3. Assembly instructions

Step 1: Mounting the holders to the base plates

1. Attach the model-specific holders to the base plates. Use the supplied screws to securely fasten the holders.
2. **Note**: The screws are screwed directly into the plastic. Be careful not to overturn the threads to ensure a secure attachment.
3. Ensure all holders are firmly mounted to the base plates.
4. The holders are attached to the base plate with countersunk screws countersunk M5x10mm and hex M5x25.

Step 2: Marking the Drill Holes

    1. Hold the first base plate with the mounted holders at the marked position on the wall.

    2. The top edge of both base plates must be aligned and level.

    3. Set a distance of 30 cm between the base plates.

30 cm

    4. Use the pencil to mark the drill holes through the holes in the base plate on the wall.

    5. Repeat this process for the second base plate, ensuring both plates are at the same height and the correct distance apart.

Step 3: Drilling the Holes

    1. Choose a drill bit that matches the size of the supplied dowels.

    2. Drill the marked holes in the wall. Keep the drill straight to ensure precise holes.

    3. Remove the drill dust from the holes.

Step 4: Attaching the Base Plates to the Wall

    1. Insert the dowels into the drilled holes.

    2. Hold the base plate with the mounted holders against the wall and screw it in place with the supplied screws.

    3. Repeat this process for the second base plate.

Step 5: Attaching the Motorcycle Case

    1. Hang the motorcycle case on the holder using first the lower pins and then let the upper holder click.

    2. Check that the case is securely and firmly attached to the holder.

    3. Familiarize yourself with the use of this product and repeat the attachment process several times until you master the handling.

4. Usage instructions

Load Limits

The maximum load of the wall bracket is 15 kg. Do not exceed this limit to avoid damage to the bracket or the wall.
The motorcycle cases should only be hung on the wall bracket when empty.

Care and Maintenance

Regularly check the fastenings of the bracket to ensure they are secure.
If you notice any signs of damage, replace the affected parts to ensure safety.

5. Troubleshooting

Common Problems and Solutions

- Problem: The bracket is loose on the wall.
    - Solution: Check if the screws are tightened. If necessary, tighten the screws. Ensure the dowels are properly seated in the wall.
- Problem: The motorcycle case hangs crooked.
    - Solution: Check if the holders are correctly mounted to the base plates and if the base plates are straight on the wall. Adjust the holders if necessary.
- Problem: The screws strip in the plastic.
    - Solution: Remove the screws and check the threads. If necessary, use larger screws or special plastic dowels to ensure a secure attachment.

Contact Information

If you need further assistance or encounter problems not listed here, please contact our customer service:

- Email: info@snoto.de
- Website: www.snoto.de

6. Warranty and Service

Warranty Conditions

- No additional warranty is offered. The statutory warranty remains unaffected.
- The statutory warranty covers material and manufacturing defects that occur with normal use.
- Damage caused by improper assembly, overloading, or improper use is excluded from the warranty.

Warranty Claims

- To make a warranty claim, please contact our customer service and have the purchase receipt ready.
- Our customer service will guide you through the process of returning and exchanging or repairing the product.

Service Information

- For repairs outside the warranty period or for additional services, you can also contact our customer service.
- We offer spare parts and repair services to extend the life of your wall bracket.

Contact Information:

- Email: info@snoto.de
- Website: www.snoto.de

7. Appendix

Technical Data

- Material: PLA plastic (3D-printed)
- Dimensions of the base plates: 295 mm x 100 mm x 10 mm
- Weight: 200 g per holder unit
- Maximum load: 15 kg
- Color: Black
- Mounting screws: 3.5 mm x 25 mm (included)

Declaration of Conformity

- This wall bracket complies with the relevant safety and quality standards.
- Manufacturing is carried out according to the guidelines for 3D-printed products and is subject to regular quality controls.